

NOVAX® LEATHER PROTECTOR GLOVES

NOVAX® Leather Protector Gloves add an extra layer of safety for rubber insulating gloves. They are to be used only for mechanical protection against cuts, abrasions and punctures for rubber gloves and mittens. It should always be worn over NOVAX® Rubber Insulating Gloves to meet ASTM F696-06 standard. Our Leather Protector Gloves are manufactured from top grain cowhide or goatskin.

The 9.5"-10" NOVAX® Leather Protector Gloves comes with zig zag elastic wrist while an adjustable nylon strap with buckle is equipped for longer gloves.



WHERE WOULD I USE IT?

- GENERAL INDUSTRIAL WORK
- OPERATING MACHINERY
- CONSTRUCTION
- HEAVY DUTY APPLICATIONS
- MATERIAL HANDLING

HOW WOULD I USE THIS PRODUCT?

- PULL GLOVES ONTO HANDS
- MAKE SURE GLOVES ARE POSITIONED COMFORTABLY
- IF WORKING IN AN ELECTRICAL AREA WEAR RUBBER INSULATED GLOVES, DO NOT WORK IN THIS AREA WITHOUT THESE RUBBER GLOVES
- TAKE GLOVES OFF WHEN FINISHED, PLACE IN BAG AND STORE IN SAFE AREA

TECHNICAL SPECIFICATION

Product code	Material	Class	Length	Leather Thickness (mm)	Size
G-LPG-W10S	Goat Skin	00 - 0	9.5"-10"	Goat Skin : 0.7-0.9	7, 8, 9, 10, 11, 12
G-LPG-X12S	Goat Skin, Cowhide gauntlet	1 - 2	10"-10.5" for size 7-8 11.5"-12" for size 9 -11	Goat Skin : 0.7-0.9 Cowhide : 1.2-1.7	7, 8, 9, 10, 11, 12
G-LPG-M13S	Goat Skin, Cowhide gauntlet	3 - 4	12.5"-13"	Goat Skin : 0.7-0.9 Cowhide : 1.2-1.7	9, 10, 11, 12

WARNING: Do not use leather protectors alone for protection against electric shock. Serious injury or death will result. Always use proper insulating rubber gloves. Proper care of leather protectors is essential to user safety. Inspect the leather protectors when inspecting rubber gloves. Metal particles, imbedded wire, abrasive materials or any substance that could physically damage the rubber gloves must be removed from the protector before use.

* Specifications of the product are subject to change without prior notice for further enhancements.



Marketing Office
G.B. INDUSTRIES SDN BHD
No. 75-2, Jalan USJ 21/11, 47630
Subang Jaya, Selangor D.E. Malaysia.

Tel : +603 8023 8899
Fax : +603 8023 8877

sales@novax-intl.com



www.novax-intl.com
USA • Europe • MALAYSIA • China • India